

WPR1500-LDO MP Receiver V2.1 Reference Design User's Guide

1 Introduction

This document describes how to use the WPR1500-LDO medium power receiver reference board designed by NXP Semiconductors. It supports 15 W, it is built according to the WPC Qi V1.2.2 specification, and has the capability to support future standards. It is a low-cost reference solution that can be easily customized through the FreeMASTER.

Contents

1. Introduction	1
2. System Features	2
3. Package Checklist	2
4. System Block Diagram	2
5. Hardware Description	3
6. Getting Started	4
7. References	31
8. Revision History	31




Figure 1. WPR1500 reference board – LDO

2 System Features

The WPR1500 medium power receiver reference board has the following features:

- Compliance with the medium power WPC Qi V1.2.2 specification
- Input power (3.5 V – 20 V AC peak) from the transmitter through the receiver coil
- Output power of 15 W (5 V @ 3 A)
- Support of FSK communication signals from the medium power transmitter
- Hardware protection of rectifier voltage, output voltage and output current
- Small PCB size (40 mm × 40 mm)
- FreeMASTER tool to enable customization and calibration

3 Package Checklist

Table 1. Package checklist

Name	Count
WPR1500-LDO board	1
WPR1500-debug board	1
10-pin SWD debugging cable	1

4 System Block Diagram

The WPR1500 medium power receiver wireless charging system is shown in Figure 2.




Figure 2. Wireless charging system overview

For the WPC Qi information, visit www.wirelesspowerconsortium.com/developers/.

5 Hardware Description

5.1 Reference board block diagram




Figure 3. WPR1500 receiver board block diagram – LDO

5.2 Modules explanation




Figure 4. WPR1500-LDO board modules overview

- **Controller**
The NXP WPR15xx MCU is the central controller of the WPR1500 receiver board. The chip is a higher integration receiver controller MCU for wireless power transfer application. The WPR15xx is an ARM[®] Cortex[®] M0+ core ASSP with NXP's UHV technology. It includes the FSK and CNC models that allow easy development for bi-directional communication architecture between the transmitter and receiver. The PGA model handles small signals that ease the solution for foreign object detection. The USB / adapter switcher sets the priority between wired and wireless charging. The following modules are used in this application:
 - LDO – provides 5 V and 3 A output to the down system
 - CNC controls the communication and provides AC protection
 - High-voltage input PMC module with three power modes: Run, Wait, Stop
 - Programmable-gain amplifier (PGA) with differential input and output
 - FSK demodulation timer (FSKDT)
 - WDOG with independent clock source
- **Rectifier**
The rectifier uses a self-driven sync type. It has the following characteristics:
 - Input voltage : 3.5 – 20 V AC peak
 - Output voltage: 3.5 – 20 V DC
- **Communication**
 - The ASK differential bi-phase signal is modulated by switching the modulation capacitor
 - The FSK signal is demodulated by the CNC and FSKDT modules
- **USB switch**
 - The CNC module automatically detects the input voltage once the wired power is plugged in, and switches on wired power when the input voltage is in the range of 4.5 V – 5.5 V.

6 Getting Started

6.1 System development environment

The WPR1500 receiver board supports debugging using the IDE (IAR, Keil MDK or CodeWarrior) and FreeMASTER tools. [Figure 5](#) shows the setup of the debug connection. The debugger and the debug board are placed between the PC and the receiver board.

To download an image onto the WPR1516 chip, connect a debugger (J-Link or P&E-Multilink FX) to the SWD port of the debug board, and connect the debug board to the receiver board using a 10-pin cable. The micro interface in the debug board needs to be connected to the USB to get power.

To monitor the working status of the WPR1500 receiver board, short jumper J110 on the debug board, and connect the micro interface on the debug board to the PC through a micro USB cable.

[Figure 5](#) shows the connection diagram and [Figure 6](#) shows a real image.




Figure 5. Debug connections




Figure 6. Development environment

For details on the J-Link debugger, visit nxp.com and search for “J-Link”.

6.2 Downloading and debugging firmware

6.2.1 Connecting the J-Link debugger

Connect the J-Link debugger to the SWD port of the debug board, and then connect the debug board to the receiver board using a 10-pin cable.

NOTE

The micro interface in the debug board needs to be connected to the USB to receive power. Ensure that the jumper J110 is connected before the download.

The connection is shown in [Figure 7](#).




Figure 7. J-Link connection

When the J-Link is plugged into the PC, it can be found in Windows Device Manager, as shown in [Figure 8](#) and [Figure 9](#).




Figure 8. J-Link debugger plugged in



Figure 9. P&E multilink debugger plugged in

6.2.2 Downloading an existing WPR1500 project using IAR

To download an existing WPR1500 project using IAR, perform the following steps:

1. Set up the IAR embedded workbench.

The IAR embedded workbench tool is required. Because the receiver driver library is already included in the lib folder of the wireless charger application project, you can open the application project and build the applications directly whenever the wpr_lib.a is ready.

The configurations in MWPR1516_config.h are set for the BUCK board by default. To build this project for the LDO board, change the macro definition BOARD_OUT_TYPE from #define BOARD_OUT_TYPE OUT_TYPE_BUCK to #define BOARD_OUT_TYPE OUT_TYPE_LDO. Then rebuild all the file in the project.

The demo application workspace files are located in:

<software_package>/build/wpr1500/iar/WPR1500_REF/WPR1500_REF.eww

2. Build a project.

Click the “Rebuild All” button:




Figure 10. Building a project

When the build is completed, the IAR displays the following information in the build window:




Figure 11. Successful project build

3. Ensure that the debugger is configured properly in the project options.
The flash loader must be selected to support downloading of the binary into the internal flash:




Figure 12. Flash loader configuration

When using the J-Link as the debugger, select J-Link/J-Trace:




Figure 13. Debugger driver configuration – J-Link

When using the P&E Multilink as the debugger, select PE micro:




Figure 14. Debugger driver configuration – PE micro

The USB Multilink must be configured in the PE micro settings:




Figure 15. Debugger configuration for PE micro

- Download the project.

After the application is built successfully, click on the “Download and Debug” button to download the application to the target device.



Figure 16. Download and debug button

Programming of a project is shown in Figure 17.




Figure 17. Programming a project

Getting Started

5. After the application is downloaded to the target device, the debugger stops executing at the start of the main() function:




Figure 18. Stop at main() when run debugging

6.2.3 Downloading an existing WPR1500 project with KEIL μ Vision5

To download an existing WPR1500 project with KEIL, perform the following steps:

1. Set up the KEIL μ Vision MDK.

Because the receiver driver library is already included in the library folder and platform folder of the wireless charger application project, you can open the application project and build the applications directly whenever the wpr_lib.lib is ready.

The configurations in MWPR1516_config.h are set for the BUCK board by default. To build this project for the LDO board, change the macro definition BOARD_OUT_TYPE from #define BOARD_OUT_TYPE OUT_TYPE_BUCK to #define BOARD_OUT_TYPE OUT_TYPE_LDO. Then rebuild all the file in the project.

The demo applications workspace files are located in:

<software_package>/build/wpr1500/keil/WPR1500_REF/WPR1500_REF.uvprojx

2. Build a project.

Click the “Rebuild” button.




Figure 19. Building a project

When the build is complete, KEIL displays this information in the build window as follows.




Figure 20. Building a project successfully

3. Ensure that the debugger configuration is correct in the project options.
The flash loader must be selected to support downloading the binary to the internal Flash.




Figure 21. Flash loader configurations

If using the J-Link as debugger, choose J-link/J-Trace.




Figure 22. Debugger configurations for J-Link

If using P&E Multilink as the debugger, choose the PE micro.




Figure 23. Debugger configurations for PE micro

4. Download the project.

After the application is built successfully, click the “Download” button to download the application to the target device.




Figure 24. Download button

Program a project.




Figure 25. Programming a project

5. After the application is downloaded to the target device, click “Start/Stop Debug Session” to debug the code. The debugger stops executing at the start of the main() function.




Figure 26. Stopping at main() when running debugging

6.2.4 Downloading an existing WPR1500 project with CodeWarrior

To download an existing WPR1500 project with CodeWarrior, perform the following steps:

1. Set up the CodeWarrior.

As the WPR1516 chip is a new series chip for CodeWarrior, install CodeWarrior V10.6.4 with update 5 or later. To install update 5 package successfully, check for an update to let CodeWarrior install some essential components.

Because the receiver driver library is already included in the lib folder and platform folder of the wireless charger application project, you can open the application project and build the applications directly whenever the libwpr_lib.a is ready.

The configurations in MWPR1516_config.h are set for the BUCK board by default. To build this project for the LDO board, change the macro definition BOARD_OUT_TYPE from #define BOARD_OUT_TYPE OUT_TYPE_BUCK to #define BOARD_OUT_TYPE OUT_TYPE_LDO. Then rebuild all the file in the project.

The demo applications workspace folder is located in:

<software_package>/build/wpr1500/cw/WPR1500_REF

2. Build a project.

Click the **Clean Project** button to clean project, and then click the **Build Project** button.





Figure 27. Build the project

When the build is complete, CodeWarrior displays this information in the Console window as follows.



```

CDT Build Console [WPR1500_REF]
'Invoking: ARM Ltd Windows GNU Create Listing'
"C:/Freescale/CW MCU
v10.6/Cross_Tools/arm-none-eabi-gcc-4_7_3/bin/arm-none-eabi-objdump" -h -S WPR1500_REF.elf >"WPR1500_REF.lst"
'Invoking: ARM Ltd Windows GNU Print Size'
"C:/Freescale/CW MCU
v10.6/Cross_Tools/arm-none-eabi-gcc-4_7_3/bin/arm-none-eabi-size" --format=berkeley WPR1500_REF.elf
  text      data      bss      dec      hex filename
 14552      212     1940    16704    4140 WPR1500_REF.elf
'Finished building: WPR1500_REF.siz'
' '

```

Figure 28. Build the project successfully

3. Select **Debug Configurations** to select debugger setting. Two supported debugger settings are already configured in the project.




Figure 29. Flash loader configurations

When using the J-Link as the debugger, select **WPR1500_REF_FLASH_Segger Jlink_Trace**. When using the P&E Multilink as the debugger, select **WPR1500_REF_FLASH_PnE U-MultiLink**. If you want to change some parameters, click the **Edit** button in the Target setting subpage. The configuration interface is shown as follows.




Figure 30. Debug configurations

4. Download and debug the project.

After the application is built successfully, click the Debug button in the above-mentioned configuration dialog. Then the project code is downloading and the debugger stops executing at the start of the main() function.




Figure 31. Stop at main() when running debugging

6.3 Debugging the WPR1500 receiver with FreeMASTER

6.3.1 Connecting the debug cable

The FreeMASTER debug connection is shown in [Figure 32](#). Ensure that the jumper J110 is removed before debugging, and then put the receiver on the transmitter panel.




Figure 32. FreeMASTER debug connection

6.3.2 Setting FreeMASTER project options

1. Set the symbol file for your project.

Select a symbol file from FreeMASTER Project -> Options -> MAP Files, as shown in the following figure. The IAR project is used as an example.




Figure 33. Selecting a symbol file

2. Select a communication interface for FreeMASTER.

Select **Plug-in Module** in **FreeMASTER Project** -> **Options** -> **Comm**, as shown in the following figure. Then select **FreeMASTER Segger/Jlink Communication Plug-in**.




Figure 34. Communication interface setting

6.3.3 Debugging using FreeMASTER

NXP provides the FreeMASTER GUI tool to monitor the system working status. Open WPR1500_REF.pmp with this tool, start up the RX board, and click the red Start/Stop button. For the FreeMASTER tool, visit nxp.com/Freemaster.

The FreeMASTER GUI can be used to monitor the system state and change some parameters manually if necessary. The user can get the system error code through the oscilloscope in the GUI.




Figure 35. FreeMASTER GUI tool

The control page includes three tabs: Current/PGA Calibration, FOD Calibration, and System Control. The output current calibration function is enabled when the macro `ADC_CALIBRATION_FREEMASTER` is set to 1.

After getting the calibration result, click the **Store to flash** button to save these parameters in flash. These parameters are used to calibrate the output current every time when the RX board is started. The internal PGA calibration function is disabled by default because of the flash limitation. When this function is enabled, the calibration result can also be saved in flash by default.

The FOD Calibration function can work offline. The user needs to measure some parameters and fulfill them in this page. When calibration is complete, the parameters that can be used in the project code are listed in the bottom area of this page.

The System Control page is used to control the system manually when RX works properly. It can set the expected Vrec voltage, enable or disable output, set the control error packet value, and so on. This function is useful to debug the system in details.

MPRX FreeMASTER GUI

Current/PGA Calibration FOD Calibration System Control

FOD Calibration for BUCK board

In order to keep the parameters stable and record value easily, user can use DC power supply to provide input power. Thus Vrec can be adjusted easily. The output current of the DC power supply and Vrec, Vout and Iout need to measure by multimeter.

Here we assume that the input current of MCU is a constant and do not change with Vrec voltage. We

Name	Value	Unit	Period
CtlError	0	DEC	0
output_enable	1	DEC	0
Iout	1154	DEC	0
Vout	5084	DEC	0
Vrec	5118	DEC	0
system_error_flag	0	DEC	0
vrec_control_expected_value	5100	DEC	1000
rect_voltage_average1	5117	DEC	1000
out_current_average1	1070	DEC	1000
keep_control_error_zero_flag	0	DEC	1000
vrec_control_manually_flag	0	DEC	1000
disable_output_manually_flag	0	DEC	1000
control_error_manual_limit	255	DEC	1000

Figure 36. Control page of the FreeMASTER GUI

6.4 Testing

6.4.1 Signals on the board

The main signals on the WPR1500 reference board are shown in [Figure 37](#).




Figure 37. Test points on the WPR1500-LDO board

Testing points on the WPR1500 LDO board are as follows:

- TP106: USB input voltage
- TP109: VREC
- TP107 & TP108: GND
- TP111: Drive voltage of the LDO MOSFET

The following examples show how to measure and debug the board follow.

1. [Figure 38](#) shows the input voltage and communication signal from ping phase to power transfer setup.
 - Channel 1: rectifier DC output voltage VREC
 - Channel 2: coil AC input voltage V_Coil
 - Channel 3: communication signal CTX
 - Channel 4: coil AC input current I_Coil




Figure 38. Ping process of the wireless power receiver

- System response measurement for a 3 A load is shown in Figure 39.




Figure 39. System response for a 3 A load

- System response measurement for increasing the load gradually from 0 A is shown in [Figure 40](#).




Figure 40. System response for adding the load gradually

- System response measurement for reducing the load gradually to 0 A is shown in [Figure 41](#).




Figure 41. System response for reducing the load gradually to 0 A

7 References

- NXP wireless charging solution page:
nxp.com/wirelesscharging
- NXP FreeMASTER tool page:
nxp.com/Freemaster
- WPC page:
www.wirelesspowerconsortium.com

8 Revision History

This table summarizes revisions to this document.

Table 2. Revision history

Revision number	Date	Substantive changes
0	09/2016	Initial release

How to Reach Us:

Home Page:
nxp.com

Web Support:
nxp.com/support

Information in this document is provided solely to enable system and software implementers to use Freescale products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits based on the information in this document.

Freescale reserves the right to make changes without further notice to any products herein. Freescale makes no warranty, representation, or guarantee regarding the suitability of its products for any particular purpose, nor does Freescale assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters that may be provided in Freescale data sheets and/or specifications can and do vary in different applications, and actual performance may vary over time. All operating parameters, including "typicals," must be validated for each customer application by customer's technical experts. Freescale does not convey any license under its patent rights nor the rights of others. Freescale sells products pursuant to standard terms and conditions of sale, which can be found at the following address: nxp.com/SalesTermsandConditions.

Freescale and the Freescale logo are trademarks of Freescale Semiconductor, Inc., Reg. U.S. Pat. & Tm. Off. All other product or service names are the property of their respective owners. All rights reserved.

© 2016 Freescale Semiconductor, Inc.

Document Number: WPR1500LDOMPUG
Rev. 0
09/2016

