

Alpha Wire Part Number Ordering Guide

Step 1: Start with the base part number (sometimes classified as the item number).

Ex: 5002C, 9008A, V16001, 1550, FIT-221-1/8

Step 2: Then choose jacket color, use the abbreviation

Color Putup	Color (jacket)
BK	Black
BL	Blue
BR	Brown
GR	Green
GY	Green/Yellow
NA	Natural
OR	Orange
RD	Red
SL	Slate
VI	Violet

Step 3: Choose put up code, use the abbreviation for the part number

Put Up Code	Description
001	1000 FT
002	500 FT
005	100 FT
021	Box 1000 FT
066	14X6 Inches

Step 4: Alpha Wire Part Number Examples

Item Number: 5002C

Item Color: Gray/Slate

Item Put Up: 1000 Ft

Part Number System: 5002C SL001

Item Number: 3070

Item Color: Black

Item Put Up: 100 Ft

Part Number System: 3070 BK005

Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

Alpha Wire:

[1217C SL001](#) [1219/37C SL005](#) [9058X BK001](#) [9062A BK001](#) [9062A BK002](#) [9062AC BK002](#) [9058X BK002](#) [9058X BK005](#) [9062A BK005](#) [832 SL078](#) [535B BK076](#) [548F BK078](#) [777B SL076](#) [547F BK078](#) [782 BK078](#) [781 BK078](#) [684/4 BK038](#) [776 BK078](#) [537 BK078](#) [682/4 BK038](#) [684/2 BK038](#) [681/4 BK038](#) [683/2 BK038](#) [706/2R BK032](#) [760/2 BK038](#) [682/2 BK038](#) [705/2R BK032](#) [704/2R BK032](#) [652 BK038](#) [651 BK038](#) [640 BK038](#) [704/4R BK032](#) [710/4R BK032](#) [712/4R BK032](#) [707/4R BK032](#) [545B BK076](#) [601B WH076](#) [707R BK032](#) [654 BK038](#) [775 BK078](#) [778 BK078](#) [683/4 BK038](#) [831 SL078](#) [801 BK078](#) [702R BK032](#) [715/4R BK032](#) [783 BK078](#) [780B SL076](#) [545 BK078](#) [540 BK078](#) [538 BK078](#) [531 BK078](#) [507F BK078](#) [704R BK032](#) [722/2R BK032](#) [705R BK032](#) [760/4 BK038](#) [6458 BK005](#) [M4182 BK001](#) [M4220 BK001](#) [532 BK078](#) [546 BK078](#) [550F BK078](#) [680/4 BK038](#) [780 SL078](#) [6458 BK002](#) [953 BK078](#) [58411 SL002](#) [1775C SL002](#) [6333 SL002](#) [6398 SL002](#) [6334 SL001](#) [1454 BK005](#) [3247 SL001](#) [1715 SL002](#) [2421C SL005](#) [6419 SL002](#) [1604 SL030](#) [2211C SL002](#) [6460 OR001](#) [2423C SL021](#) [615 BK078](#) [1702 SL001](#) [6054C SL001](#) [6311 SL002](#) [9104 BK002](#) [6073C SL005](#) [M4182 BK002](#) [6395 SL002](#) [1215C SL005](#) [57003 SL002](#) [6357 SL002](#) [6384 SL001](#) [6332 SL005](#) [6308 SL005](#) [6410 SL001](#) [57604 SL001](#) [2465C SL001](#) [2254 SL002](#) [1891C SL005](#)