

Montageanweisung
multipac









Assembly instructions
multipac

Instructions de montage
multipac

Grundausbau 1-4 HE

Basic version 1-4 U

Version de base 1-4 U


				
1 (2x)	2 (1x)	3 (1x)	4 (2x) *	
				
1HE/U	4x	4x	8x	
2-4HE/U	8x	-	8x	
				
			7 (2x) *	8 (4x) *

* Pos 4,7,8 sind im Lieferumfang nicht enthalten

* Pos 4,7,8 are not supplied

* Pos 4,7,8 non compris dans la livraison











1



Grundausbau 5-6 HE

Basic version 5-6 U

Version de base 5-6 U


					
5HE/U	2x	2x	2 (1x)	3 (1x)	4 (2x) *
6HE/U	4x	-			
					
	5 (16x)	6 (8x)	9 (1x)		7 (2x) *
					
					8 (4x) *


* Pos 4,7,8 sind im Lieferumfang nicht enthalten

* Pos 4,7,8 are not supplied



* Pos 4,7,8 non compris dans la livraison

2





3



4

