98 42 937 0201



Pushing Performance

HARTING Han® GND



Han® GND - Mateable Potential Equalization

The new Han[®] GND series now enables pluggable grounding systems Han[®] GND (Han[®] Ground) is the innovative HARTING solution for potential equalization. The new connector series makes it possible to execute grounding systems in a pluggable design for the first time.

The use of connectors has been well-established in the electrical cabling of machines and systems for many years. The advantage is quick and error-free commissioning. Potential equalization lines are still being permanently connected, which is relatively time-consuming and can be subject to errors. HARTING's remedy: the Han[®] GND. The single-pole connector in the robust IP 65 plastic housing is designed for stranded wires from 10 - 35 mm² and is optionally available in crimp or axial screw termination. The latter has the advantage that the lines can be connected without a special tool. A simple screwdriver is all it takes to achieve a quick and easy reliable connection. Extra connector mating security can be provided by the use of additional locking elements that prevent unintentional opening.



Han[®] GND

Features

- · New: First connector for potential equalization
- · Slim, space saving design
- · Low cost plastic hoods and housings
- · Colours: green and yellow
- Separate axial screw contacts can be terminated without any special tools directly to the wire.

Technical characteristics

Specifications

Hoods/Housings

Material - hoods/housings - seal - cable seal Limiting temperatures Flammability acc. to UL 94 Degree of protection according to DIN EN 60 529 for coupled connectors Mechanical working life Cable diameter

Modules

Number of contacts Material Limiting temperatures Flammability acc. to UL 94 Mechanical working life

Crimp Contacts

Material Surface - hard-silver plated Contact resistance Crimp terminal - wire gauge¹⁾

Axial Screw Contacts

Material Surface - hard-silver plated Contact resistance Screw terminal

- wire gauge¹⁾ - AWG
- hexagonal driver
- tightening torque

polycarbonate NBR polyamide -40 °C ... +85 °C V 0

IP 65 ≥ 500 mating cycles 7.5 - 14 mm

1 polycarbonate -40 °C ... +125 °C V 0 ≥ 500 mating cycles

copper alloy

3 µm Ag ≤ 0.3 mΩ

10 ... 35 mm²

copper alloy

3 µm Ag ≤ 0.3 mΩ

10 ... 35 mm² 6 ... 2 SW 4

mm²	10	16	25	35
Nm	6	6	7	8

Han [®] GND			HARTING
Number of contacts 1 Motocoble Dotontial Equalization			
Mateable Potential Equalization	Dorf Number	Deruitare	Dimensions in mm
Identification Hood top entry	Part-Number 09 14 001 0430	Drawings Ø26,5	
Unlocking Protection	09 14 000 9938	<u>19,8</u>	
Housing	09 14 001 0330		Montageausschnitt
Hoods, cable to cable	09 14 001 0730	<i>L</i> ² 5W24 <i>Ø</i> 26,5	
Gender changer / coupler male / male	09 14 001 9901	79,4	

Han® GND



* Crimp zone acc. to DIN EN 46 235 For further information see chapter 99 (Tools) in the main catalogue "Industrial Connectors Han®"

Han[®] GND

HARTING

Assembly and construction

Assembly

Please use fine stranded wire (Class 5) which is recommend for the axial screw termination.



Do not twist the stripped wire!

1.

2.

turn clockwise

Please strip the wire. All suitable wire gauges have to be stripped with a length of 13 mm (acc. to Class 5 wire). Insert stripped wire into the terminal and push fully inside. Pay attention that all fine stranded wires are inserted in the contact.





Please insert suitable torque key (SW 4) into the contact from mating side and turn the axial screw clockwise. For that purpose secure the axial screw with a spanner (SW 11). Tighten the screw to the specified torque value.

Secure axial screw

Han[®] GND

Assembly and construction



- 4. Pus and
- Insert the installed cable through the cable gland into the Han[®] GND housing! Push the axial screw contact into the module until you hear an audible click, which is the indicator that the contact snaps into position.
 - Push the module back into the housing and turn the cable gland clockwise.
 - Mount the module in the housing with the enclosed screws.



Protection against unintentional opening

1.

5.

3.

Push the unlocking protection over the opening latches to prevent an unintentional opening (the connector can only be unma ted with a separate tool).

2.

The removal of the unlocking protection can be done with a screwdriver for slotted screws (e.g. size 0.8×4.0). Insert the screwdriver in the unlocking protection slot and release the plastic latch until you are able to remove the unlocking protection with your fingers.



Pushing Performance

www.HARTING.com