



Bottom Heel of Shoe

Description:

Desco's disposable heel grounder provides a path-to-ground and does not generate a charge when used with an ESD floor. The highly visible yellow polyester fabric identifies wearers as properly grounded. The material is non-marring and will not mark floors. The disposable heel grounder is designed for single use and should be removed and disposed of after use.

Installation:

1. Insert the non-adhesive end of the heel grounder inside the shoe so that the black dot is in the center of the heel area.
2. Wrap the heel grounder around the back (or side) of shoe so that the adhesive can be adhered to the bottom of the heel.
3. Remove perforated sections section of paper from adhesive that will come in contact with the heel. Do not allow adhesive to come in contact with any part of the shoe except for the heel. The adhesive may leave a residue.
4. Step in to shoe. Disposable heel grounder is to be installed on both shoes and used with ESD flooring.
5. Test each worn foot grounder with a [Personal Grounding Tester](#)

Electrical Properties:

Dimensions: 1/2" x 12"

Resistance to Ground (Rtg): $\geq 5 \times 10^4 > 8 \times 10^5$ ohms

ITEM	DESCRIPTION	LENGTH	PKG.
17155	Disposable Heel Grounder	12"	100

Unless otherwise noted, tolerance $\pm 10\%$

Specifications and procedures subject to change without notice.

Heel Grounder, High Visibility, Disposable

DESCO

DESCO WEST: 3651 WALNUT AVE., CHINO, CA 91710 WEB SITE: Desco.com
 PHONE (909) 627-8178
 DESCO EAST: ONE COLGATE WAY, CANTON, MA 02021-1407
 PHONE (781) 821-8370

**DRAWING
NUMBER**
17155

DATE:
November
2012