

Manual Switches Mounting Hardware

FOR STRIP AND MATRIX MOUNT ASSEMBLIES














FEATURES

- Enables subpanel mounting of devices in factory assembled metal cans which are welded together in strips or matrices. Assures accurate alignment and enables pre-wiring.
- L-shaped mounting brackets conform to various panel thicknesses, using spacers.
- Simplifies panel fabrication, since only one large cutout is required.
- Facilitates printed circuit board mounting. Operating force is transmitted to mounting hardware, rather than P.C. board.
- For custom matrices contact the MICRO SWITCH Application Center.
- Mounting dimensions page 64.

AML61 MOUNTING HARDWARE ORDER GUIDE

(For standard strip mount assemblies)


AML61 B	A	5	A
Type	Mounting Bracket Orientation	Number of Cans	Mounting Bracket Location
Square cans: AML61 B (Plain finish) AML61 J (Black finish)	<p style="text-align: center;">A</p>  <p style="text-align: center;">E</p> 	<p style="text-align: center;">1 2 3 4 5 6 7 8 9* 10* 11* 12*</p> <p style="text-align: center;">*A, C, D & E orientation only.</p>	      <p style="text-align: center;">BRACKET FLUSH TO TOP OF CAN</p> <p style="text-align: center;">0.060 A 0.020 G</p> <p style="text-align: center;">0.030 B 0.045 K</p> <p style="text-align: center;">0.060 C 0.050 L</p> <p style="text-align: center;">0.120 D 0.065 P</p> <p style="text-align: center;">0.060 E 0.085 T</p> <p style="text-align: center;">1.460 F</p> <p style="text-align: center;">U NO BRACKETS</p>
Rect. cans: AML61 E (Plain finish) AML61 K (Black finish)	<p style="text-align: center;">B</p>  <p style="text-align: center;">C</p>  <p style="text-align: center;">D</p> 		

Manuals

① To order one rectangular can with mounting brackets on short sides, specify AML61EB1____ or AML61KB1____.

Example: AML61EC5A

Five rectangular cans, plain finish (unpainted), long sides abutting; type A mounting brackets on long sides, located flush with switch or indicator bezel. (Type T bracket brings top of annunciator bezel flush with top of .160 in./4,1 mm panel.)



This strip has Type F brackets for P.C. board mounting.

NON-STANDARD ASSEMBLIES

Use the order form on the following page to specify non-standard AML61 strip or matrix assemblies. You may reproduce it on your office copier, or order pads from the 800 number. Request FO-63558.

Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

Honeywell:

[AML61BA1U](#) [AML61BA2A](#) [AML61BA2G](#) [AML61BA2U](#) [AML61BA3D](#) [AML61BA3U](#) [AML61BA4E](#) [AML61BA5T](#)
[AML61BA6E](#) [AML61EB1E](#) [AML61EB1U](#) [AML61EB2T](#) [AML61EB3A](#) [AML61EB4B](#) [AML61EC3A](#) [AML61EC5C](#)
[AML61EC8D](#) [AML61ED4D](#) [AML61ED6F](#) [AML61KB1E](#) [AML61KB3E](#) [AML61KB4E](#) [AML61KB5F](#) [AML61KC3E](#)
[AML61KC5E](#) [AML61EB3T](#) [AML61ED3B](#)